


**This product may be purchased from Connevens Limited secure online store
at www.DeafEquipment.co.uk**



DeafEquipment.co.uk

Solutions to improve the quality of life





sound oasis™

Sound Card™

Model SC-200

CONGRATULATIONS!

You now own a top quality Sound Oasis™ Sound Card.

Please take a few moments to review the following important information before using this item.

Thank You!

Sound Oasis Sound Card

sound oasis™

This Sound Oasis™ Sound Card allows you to build your own personal sound library in just seconds. Simply insert into your Sound Oasis™ Ultra or Sound Oasis™ Deluxe sound system and enjoy 6 additional, authentic digital recordings.

Important Safeguards:

- Read all instructions.
- Do not touch the metal contacts on the **Sound Card**. Touching these electrical contacts with statically charged objects, including your fingers, could erase the sounds stored in the **Sound Card**.

Sound Oasis Sound Card

sound oasis™

Page 2

Page 3

- Do not put excessive pressure on the **Sound Card**.
- Do not expose the **Sound Card** to heat, cold or liquids.

Directions For Use:

1. Insert your **Sound Card** into your sound system's **Sound Card Slot** with the arrow on the **Sound Card** pointing into the slot and facing the front of your sound system.
2. Push the **Sound Card** down until you feel it meet the bottom of the slot (about 1/2" of the **Sound Card** will remain outside the slot).

3. To activate the **Sound Card** function, press the **Sound Card** button on your Sound Oasis™ sound unit.
4. To play back the sounds stored on the **Sound Card**, turn your Sound Oasis™ unit on (if not on already), and press the sound button next to the number that corresponds to the sound you want to listen to from the **Sound Card**.

(e.g. if "Ocean Rain" is the 5th **Sound Card** sound, pressing the sound button with a "5" next to it will play the "Ocean Rain" sound).

Storage Tip:

Your **Sound Card** carton can double as a storage container. If you remove the **Sound Card** from your unit, store the **Sound Card** inside its carton to protect the **Sound Card's** electrical contacts from dust and debris.

Nature sounds used under license from Solitudes® Ltd.
© 1995 Solitudes Ltd.

For a free catalog of their nature programs write to :
1131A - Leslie Street, Suite 401, Toronto, ON, Canada M3C 3L8
and/or

Madacy Entertainment Group Inc.
1865 Trans-Canada, Montréal, Québec, Canada H9P 1J1