



Solutions to improve the quality of life

**This product may be purchased from Connevens Limited secure online store
at www.DeafEquipment.co.uk**



DeafEquipment.co.uk

Solutions to improve the quality of life



GLOBAL DOOR BEACON

Installation of 9 volt Alkaline Battery:

Your "Door Beacon" is powered by a 9 volt Battery (purchased separately). USE ONLY ALKALINE BATTERY. The battery compartment is located in the bottom of the unit. To remove the cover, push in the direction of the arrow. Connect a 9 volt battery to the terminals. Position battery into the recessed compartment and replace the cover.

To mount unit on the door:

Unit should be positioned on the inside of the door of the room you will be in. An "Over the Door" Hanging Bracket is included that allows you to easily hang your "Door Beacon" on any standard door. It also allows the convenience of moving the "Door Beacon" to a different door. Attach the Hanging Bracket as illustrated below.



Γ

Insert Hanging Bracket from bottom as shown.

Your "Door Beacon" can also be hung in place on the door by installing a screw where you want the unit positioned. Hang the "Door Beacon" onto the screw by using the hole on the molded bracket at the back of the unit.

To attach the "Door Beacon" to the door with the supplied VELCRO, separate the two Velcro pieces by pulling apart. Attach the thick, plush piece of the Velcro to the inside of the door after removing the paper backing. Press the adhesive side firmly against the door. Secure the other section of Velcro to the back of the "Door Beacon" unit, first removing the paper backing and then pressing the adhesive to the unit. The "Door Beacon" can then be secured by pressing the Velcro on the unit against the Velcro on the door.

To use the Hi/Lo/Off Sensitivity Switch:

The switch on the side of the unit marked H, L, O allows for user adjustment. In the H (High) position, the sensitivity to the vibration of a knock is greater. This would be used on a thick, heavy door as an example. A thinner, lighter door might best have the switch in the L (Low) position because of lower sensitivity. Adjust the switch to suit your personal requirements to achieve maximum results.

It is suggested that the unit be turned to the O (Off) position when not in use. When unit is in the Off position, the light will not flash.

Before sending for Service:

If your "Door Beacon" ceases to operate, check & replace the battery if required. If the battery tests OK, check & replace the light bulb if required. A replacement light bulb is included. Additional replacement Light Bulbs are available from your distributor or from Global Assistive Devices, Inc.

To replace Light Bulb:

- 1) Remove 4 screws in back of cabinet (use #1 Philips Screwdriver)
- 2) Remove battery compartment cover and cabinet back.
- 3) Remove screw in middle of circuit board.
- 4) Lift printed circuit board.
- 5) Unscrew bulb (small pliers may be required)
- 6) Install replacement 290 ma 4.8 Volt Light Bulb.
- 7) Reassemble.

ONE YEAR LIMITED WARRANTY

Your "DOOR BEACON" is warranted to be free from defects in material or workmanship for one year from the date of purchase.

This warranty does not apply to light bulbs or to any unit which has been subject to misuse, negligence or accident.

At its option, Global Assistive Devices, Inc. may select to replace the entire unit rather than repair it.

For Service, return the device with dated proof of purchase, in a secure package, insured and shipping prepaid. Please include a note describing exactly what is wrong with the unit. Include \$7.50 (check, money order, Visa, Master Card or American Express) for return Shipping within the U.S.A. Send unit to:

**GLOBAL ASSISTIVE DEVICES, INC.
4950 North Dixie Highway, Suite 121
Fort Lauderdale FL USA 33334-3947**