

**This product may be purchased from Connevens Limited secure online store
at www.DeafEquipment.co.uk**



DeafEquipment.co.uk
Solutions to improve the quality of life



UNIROSS®

The rechargeable specialists

iPod Replacement Battery Pack with Case Opening Tools



UNIROSS®

The rechargeable specialists

Installation instructions

Please observe standard anti-static precautions whilst working inside the iPod. Replacing the battery requires a reasonable level of technical ability and proficiency in the use of hand tools.


Uniross Batteries S.A.S
Z.I. de la Madeleine
27, rue de la Maison Rouge
77185 LOGNES

www.uniross.com

How to replace your iPod's battery:



Begin by laying your iPod on it's back on a soft work surface.



Using the included non-scratch opening tools, begin to pry open the case, starting with the top corner.



With the opening tool wedged inside the case, carefully work your way up to the top of the iPod, unclipping the case clips as you go.



With one side of the case fully unclipped, you can now flip the main section of the iPod face down. Be careful, not to damage the ribbon cable connected to the back case cover.



Disconnect the power cable around the main board, carefully unglue and remove the battery from the glue spots. Be careful not to over extend and damage the hard drive ribbon cables.



Apply the new battery to the original orientation and glue spots and insert the connector into the socket.



Snap the main section back over to the front and snap the case back on.



Your new battery will need a minimum of three hours charging before first use.

