

**This product may be purchased from Connevens Limited secure online store
at www.DeafEquipment.co.uk**



DeafEquipment.co.uk

Solutions to improve the quality of life



EAGLE



Eagle International

Operating Instructions for

MV 10S

Megaphone

Battery installation :

- 1) Remove rear housing by rotating anti-clockwise.
- 2) Remove 2 x battery holders and insert 8 x Ever Ready type HP 7 batteries (observe correct polarity).
- 3) Replace battery holders in direction of arrows.
- 4) Replace rear housing.

OPERATION

Megaphone :

- 1) Direct megaphone at audience.
- 2) Squeeze trigger and direct speech into rear of unit.
- 3) Adjust volume to required level by means of volume control located on rear of pistol grip. In the event of feedback, reduce volume.

Siren :

- 1) Direct megaphone at audience.
- 2) Depress black on / off siren button located adjacent to volume control.
- 3) Volume control and trigger have no effect on siren.

MODEL		MV-10S		
AMP. OUTPUT		5W(RATED), 10W(MAX.)		
POWER SOURCE		12V DC(AA SIZE 1.5V x 8PCS)		
BATTERY LIFE		VOICE : APPROX. 8 HORNS. SIREN. WHISTLE		
ACOUSTIC RANGE	CITY AREA	APPROX. 250M		
	OUT SIDE THE CITY	APPROX. 900M		
DIMENSIONS	HORN DIA	190M		
	LENGTH	315mm		
NET WEIGHT (LESS BATT)		APPROX. 0.9Kg		
REMARKS		WITH SIREN	WITH WHISTLE	WITH SIREN WHISTLE