

**This product may be purchased from Connevens Limited secure online store
at www.DeafEquipment.co.uk**



DeafEquipment.co.uk

Solutions to improve the quality of life



GUARANTEE

From the moment your Geemarc product is purchased, Geemarc guarantee it for the period of one year. During this time, all repairs or replacements (at our discretion) are free of charge. Should you experience a problem then contact our helpline or visit our website at www.geemarc.com. The guarantee does not cover accidents, negligence or breakages to any parts. The product must not be tampered with or taken apart by anyone who is not an authorised Geemarc representative. The Geemarc guarantee in no way limits your legal rights.

IMPORTANT: YOUR RECEIPT IS PART OF YOUR GUARANTEE AND MUST BE RETAINED AND PRODUCED IN THE EVENT OF A WARRANTY CLAIM

Please note: The guarantee applies to the United Kingdom only.

DECLARATION: Geemarc Telecom SA hereby declares that this product is in compliance with the essential requirements and other relevant provisions of the Radio and Telecommunications Terminal Equipment Directive 1999/5/EEC and in particular article 3 section 1a, 1b and section 3.

Telephone connection : Voltages present on the telecommunication network are classified TNV-3 (Telecommunication Network Voltage) according to the EN60950 standard.



For product support and help visit our website
at www.geemarc.com
telephone 01707 384438
or fax 01707 372529




MAYFAIR



User guide

Please read this User Guide carefully in order to get the very best results from your telephone.

SETTING UP



1 - CONNECTING TELEPHONE

The plug at the end of the lead should be connected to the telephone socket.

Voltages present on the telecommunication network are classified TNV-3 (Telecommunication Network Voltage) according to the EN60950 standard.

2 - RINGER SETTING

A switch located underside of the base unit allows the ringer to be switched **ON** or **OFF**.

Outgoing calls can still be made when the switch is set to the **OFF** position.

3 - RECALL TIMING

The switch is set to a RECALL timing of 100 ms which is used in most countries in the EEC.

If you have any problems with the RECALL function, please change the switch setting to 300 ms and try again.

If the problem persists, please contact your network operator.

USING THE TELEPHONE:

1 - ANSWERING INCOMING CALLS

When an incoming call is received, the telephone will ring. To answer the call lift the handset and speak.

2 - MAKING A CALL

Lift the handset, await the dial tone and dial required number. On completion of the call, carefully replace the handset in the cradle.

3 - LAST NUMBER REDIAL

If the telephone number you have called is engaged or if you want to repeat the call to the number you dialled previously, lift the handset, await dial tone and press the **REDIAL** button. The previously dialled number will be **AUTOMATICALLY RE-DIALLED**.

4 - R, * & # BUTTONS

These are used with the new services provided on digital exchanges. For details please contact your network operator.



For product support and help visit our website

at www.geemarc.com
telephone 01707 384438
or fax 01707 372529