

**This product may be purchased from Connevens Limited secure online store
at www.DeafEquipment.co.uk**




DeafEquipment.co.uk

Solutions to improve the quality of life



INSTRUCTIONS
ALARM CLOCK WITH BED SHAKER
MODEL SBB500SS



Features shown on diagrams above:

- | | | |
|--------------------|--------------------------|----------------------------|
| 1) Alarm Indicator | 7) Alarm off Button | 13) AC Power Input |
| 2) P.M. Indicator | 8) Alarm Function Switch | 14) Tone Control Wheel |
| 3) Snooze Button | 9) Hour Button | 15) Vibrator Input |
| 4) Volume Wheel | 10) Minute Button | 16) Flashing Light Display |
| 5) Alarm Set | 11) Battery Compartment | |
| 6) Time Set Button | 12) Dimmer Switch | |

Setting the correct time-

- 1) Press and hold the Time Button (6) at the same time press the hour button (9) to advance the clock display rapidly until the hour is correct.
- 2) Press and hold the time button (6) at the same time press the MIN button (10) to advance the minute until the correct time is shown.
- 3) A lighted dot (2) in the upper left clock display indicates time is PM. For AM time indication, there is no lighted dot.

Setting the alarm time-

- 1) Simply follow the instructions mentioned under "Setting the correct time" except that you will have to press the Alarm Button (5) instead of the TIME Button.
- 2) Make sure the alarm time is correctly set for AM or PM lighted dot (2) indicates PM. Be sure to release the HOUR and MIN set buttons before releasing the ALARM button.

Waking To Alarm-

- 1) Set Function Switch (8) to choice of VIB/BUZZ or VIB or BUZZ.
- 2) Set desired volume (4) for Buzz sound.
- 3) Set alarm wake time per instructions for setting alarm time above.

Battery Backup-

To use battery backup, you can install a 9-volt alkaline battery in the back of the clock located under the battery cover (11). Battery not included. Note the LED display will not show during power failure but the clock will still be running and keeping proper time until the power comes back.

NOTE: For best results it is recommended that the battery be changed every 6 to 8 months. If the clock is not use for a while, it is recommended to remove the battery to avoid leakage.

Shutting Off Alarm-

Alarm can be shut off temporary for the day or permanently shut off.

- 1) When the alarm goes off, simply press the AL off button (7) the alarm will shut itself off for the day and come back on the next day at the same time if alarm setting has not changed.
- 2) To shut the alarm off permanently, slide function switch (8) to off position. Alarm will not come on until Function Switch (8) is set to "VIB" or "BUZZ" or "VIB/BUZZ" position.

Snooze Operation-

SNOOZE button (3) - press after alarm has sounded. The alarm will be turned off for 9 minutes for extra sleep. The alarm will come back again after 9 minutes. You may repeat many times up to 1 hour.

Alarm-

Set the alarm time you wish and slide the VIB / BUZZ / OFF (8) switch to the desired position. Set to VIB for bed shaker and BUZZ for sound, or VIB/BUZZ for both.

Tone-

Adjust the tone (14) by rotating the tone wheel located on the right hand side just below the volume wheel (4) until you reach desired level.

Volume-

To adjust the volume (4) rotate the wheel located on the upper right hand side.

Bed Shaker / Vibrator- Figure B

- 1) Attach the bed shaker jack to the back of clock at VIBRATOR input (15).
- 2) To turn on vibrator slide function switch (8) to VIB or VIB/BUZZ position.
- 3) Place vibrator under mattress or pillow.

AC-9V Power Input -

Attach the AC power supply input to the side of clock at AC-9V IN (13) next to the VIBRATOR input (15). smaller input of the two. **Important:** do not confuse AC input with vibrator input.